



U.S. Army Research, Development and Engineering Command

The CREATIVE Decontamination Performance Evaluation Model

Presented by Erin E. Shelly
Edgewood Chemical Biological Center



CREATIVE
model



TECHNOLOGY DRIVEN.
WARFIGHTER FOCUSED.


Military Operations Research
Society Symposium

June 2008


Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE 01 JUN 2008		2. REPORT TYPE N/A		3. DATES COVERED -	
4. TITLE AND SUBTITLE The CREATIVE Decontamination Performance Evaluation Model				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Edgewood Chemical Biological Center				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release, distribution unlimited					
13. SUPPLEMENTARY NOTES See also ADM202527. Military Operations Research Society Symposium (76th) Held in New London, Connecticut on June 10-12, 2008, The original document contains color images.					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT UU	18. NUMBER OF PAGES 36	19a. NAME OF RESPONSIBLE PERSON
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified			

- Develop a semi-empirical, deterministic model to characterize and predict *laboratory-scale* decontaminant efficacy and hazards for a range of:
- chemical agents (current focus on HD)
 - operational surfaces common to ground vehicle, air craft, equipment construction (e.g., aluminum, glass, CARC, silicone)
 - realistic threat challenges (0.5-10 g/m²)
 - environmental conditions (10-40 °C)
 - and decontamination process parameters (Decon, residence time).

The model will enable faster characterization of decontaminant performance and provide the capability to predict performance and hazards at untested conditions.



Decontamination is a complex, interacting system. A firm foundation at the laboratory scale is required to understand the perturbations and complexities encountered in the field.



A multi-generation model is proposed to build the necessary tools required to model a full scenario while providing usable tools at each generation stage.

Each Generation provides:

- Distinct value and information.
- Each generation builds upon the foundation adding layers of complexity building towards a full scenario.

This talk applies to the construction of the 1st Generation Foundation Laboratory Model

Decon Treatment Process: Variables, Physics and Chemistry Affecting Decon Performance & Post-Hazards

1. Precondition:

- Temperature uniformity over surface
- if hydrophilic surface, ° hydration / water equilib.

2. Contamination:

- Environment temperature and humidity of surface and contaminant
- Contamination density
- Contaminant application: # of drops, droplet size and pattern
- Contaminant surface area coverage
- Contaminant application: pipette, bomb, brush contact, etc.
- Surface properties: non-sorptive, sorptive, complex etc.


Contaminate




3. Aging:

- Environment temperature and humidity
- Contaminant droplet area as function of time (spreading)
- Aging duration (time)
- Air velocity
- Evaporation
- Sorption rate
- Transfer coefficients etc.

Age



Rinse



4. Pre-Rinse:


- Rinse water composition (water, soapy, etc.)
- Rinse volume
- Flow rate
- Applicator
- Physical removal / relocation of hazard.

etc.


5. Decontaminant:

- Decon volume
- Decon residence time
- Time since contamination for onset of decon.
- Physical state (solid, liquid, vapor)
- Phase (liquid, foam, aerosol)
- Applicators: pipette, sprayers, brushes, wipes
- Application process: force of application, how long brushed?
- Decon: contaminant surface coverage
- Surface orientation: horizontal, vertical, top, bottom
- Surface properties: non-sorptive, sorptive, complex
- Environment temperature and humidity
- Interferences: decon-material reactivity, etc.

Decon



Rinse



Dry



8. Post-Hazards

Vapor Hazard: mass transport mechanism, scenario, air flow rate, air change rate, time post decon, temp. and %RH, route of exposure, sampling method, etc.

Contact Hazard: contact duration, body region in contact, contact pressure, skin condition (wet vs dry), time post decon, temp. and %RH, sampling method in testing, etc.

6. Post-Rinse:

- Rinse water composition (water, soapy, etc.)
- Rinse volume
- Flow rate
- Applicator etc.

7. Drying:

- Environment temp. and humidity
- Dry time duration
- air velocity over surface
- Amount of water remaining at time of hazard assessment (i.e., wet skin cases typically more hazardous than dry for contact test) etc.



Model construction requires control or measurement of these variables to characterize the core physics representing the model foundation.

Necessary level of control is only available in the laboratory.

As layers of complexity and process steps are introduced data variance and number of variables increase.

Representation - does not necessarily include every variable, physical or chemical properties.


Decontamination is Mass Transport



Decontamination testing involves multiple mass transport processes resulting from agent-decon-material interactions:

- Material-Agent:** sorption
- Decon-Agent:** neutralization/solubility
- Decon-Material:** decon penetration
- Environment:** alters reaction rates and transport rates.

Post-decon hazards result from mass transport of agent from the surface that may be presented to unprotected personnel.



Decon process module


- Contains mass transport & physics of decon
- Component modules correspond to decon process steps
- Mass transport & physics are similar between agent-material-decons, difference is coefficients

Agent modules

- provide agent-material-decon specific process coefficients
- Semi-empirical methods calculate coefficients from high-quality test data

Structure enables future expansion of agents, materials* and decons without full rebuild of model

*different mass transport mechanisms (e.g., porous transport) may require further model/module development




Phase I – Conceptual Model

- Construct full model using empirical relationships and logical assumptions.
- Coefficients are determined from laboratory data
- Modular structure allows individual replacement of process algorithms.
- Conceptual model provides full model execution for limited data set.


Phase II – Physical Model

- Empirical modules are replaced by algorithms based on 1st principles physics and chemistry increasing capability for prediction
- Model retains some empirical elements to account for inadequacies in the physical model or difficulty in measurement of physical variables.



Agent Transport is Core to Decon Testing

Decon Process Module



Agent transport is determined by material properties and agent-material interactions.

Two questions to answer:

1. How much agent mass sorbed?
 - Determines how much agent to be decontaminated.
2. Where is the agent in the material?
 - Does decon penetrate to same depth to remove agent?
 - Required to predict post-decon hazards.

Material properties and agent-material interactions
determine mass transport mechanism

Non-porous sorptive transport:

Fick's Second Law (molecular diffusion based)

$$\frac{\partial C}{\partial t} = -D\nabla^2 C = -D\left(\frac{\partial^2 C}{\partial x^2} + \frac{\partial^2 C}{\partial y^2} + \frac{\partial^2 C}{\partial z^2}\right)$$

Most work in literature is for 1D;
1D models are used as a reality check
(**validation**) for the 3D model.

Porous transport:

Darcy's Law (fluid flow through porous materials – e.g., 'wicking')

Many forms in literature; application to CREATIVE under study

Some Relevant Reference Sources:

1. Crank, J., "The Mathematics of Diffusion", Oxford Science Publications
2. Smith, G.D., "Numerical Solution of Partial Differential Equations", University Press
3. Sidman, K.R., *et al*, "Absorption and Desorption of Organic Liquids by Paint Film", ARCLS-CR-82034
4. Philpot, E.F., *et al*, "Model to Describe Penetration of Skin by Sorbed Liquids by Contact", CRDEC-CR-87100
5. Clarke, A., "Spreading and Imbibition of Liquid Drops on Porous Surfaces", Langmuir 2002, 18, 2980
6. Savage *et al*, "Environmental fate of chemical agents: Final Report" ECBC-TR-532, 2007

Finite Difference Solution (using Taylor's series expansion):

$$C_{i,j,k,t+1} = [1 - 2D(r_x + r_y + r_z)] C_{i,j,k,t} + Dr_x(C_{i+1,j,k,t} + C_{i-1,j,k,t}) +$$


$$Dr_y(C_{i,j+1,k,t} + C_{i,j-1,k,t}) + Dr_z(C_{i,j,k+1,t} + C_{i,j,k-1,t})$$

C @ next time step


$$r_n = \frac{\delta t}{\delta n^2} \quad n = x, y, z$$

For $\delta x = \delta y$
and $\delta z = f \cdot \delta x$

$$\delta t \leq \frac{\delta x^2}{2D(2 + 1/f^2)}$$



Coupon grid elements




Finite element filter

C = concentration
D = diffusivity
t = time
i,j,k = coordinates
 δt = time step
 δn = spacing in n direction

Absorption boundary conditions: finite difference equation is altered at boundaries:

- 1) Drop: constant source until drop disappears
- 2) Base of substrate considered impenetrable
- 3) Sides and top of coupon allow mass to escape: rate must be determined





Variables and their sources:

- Diffusivity: literature*
- Saturation Concentration: literature*
- Substrate / Vapor Boundary parameter: CREATIVE (semi-empirically derived)
- Contact boundary parameters: CREATIVE (semi-empirically derived)
- Validation: CREATIVE

* Values may be refined based on CREATIVE results

Finite Difference Advantages:

- Allows modeling of agent distribution in substrate (**critical**)
- Allows perimeter effects including drop spreading or shrinking
- Allows calculations for asymmetric or irregularly shaped drops
- Easily adapted to other sorption approaches, e.g., Darcy's law



HD / Silicone

60 min

$D: 16 \times 10^{-7} \text{ cm}^2/\text{s}$

$C_o: 90,000 \text{ } \mu\text{g}/\text{cm}^3$

$f1: 0.75$

$\delta x, \delta y: 0.0128 \text{ cm}$

$\delta z: 0.0064 \text{ cm}$


Calculated

$\delta t: 8.533 \text{ s}$

$r_x: 0.0833$


$r_y: 0.8333$

$r_z: 0.3333$



Capabilities

- Models HD on aluminum, glass, and silicone
- Decontaminants include none (baseline), DF200, and bleach
- Data output for contact test, vapor test, and residual agent
- Model developed in Matlab
- GUI interface to input conditions and get response



Agent

Agent: HD

Volume: 1 (microliters)

Number of Drops: 2 (none)

Deposited Drop Base Radius

Measured Value: 2 (mm)

☒ Use Model Approximation

Coupon and Sampler

Coupon Material: Aluminum

Contact Sampler: Dental Dam #1

Decontaminant

Decontaminant: Bleach

Volume: 1 (ml)

Residence Time: 30 (minutes)

Concentration: 5 (%)

Air Parameters

Set Air Properties

Agent and Decontaminant Diffusivity Into Air:

Use Database Values

Aging Process Model Options

Evaporation Model: DREAM

Duration: 60 (minutes)

Time Increment: 6 (minutes)

Surface Radius of Absorbed Mass

Measured Value: 3 (mm)

☒ Use Model Approximation

Run Model

Results Summary

File Edit View Insert Tools Desktop Window Help

Number of drops: 1

Drop volume: 3 (μliters)

First contact pickup (15M): 281482.5353 (ng)

Second contact pickup (60M): 202667.4254 (ng)

Total mass remaining in coupon (RES): 810869.7017 (ng)

- CREATIVE will enable reduced testing at the laboratory scale to evaluate a decontaminant
- Objective is to predict contact- and vapor-hazards and residual agent
- Implementation of 3D mass transport modeling required to simulate contamination, decontamination, and prediction of hazards
- Agent modules enable future incorporation of new agents, materials, and decons
- Implementation of physical model for agent transport processes enables more confident prediction (and extrapolation) of post-decon hazards
- Approach developed to use indirect characterization of decontamination efficacy in the material to build semi-empirical decon model
- This model provides the laboratory-scale foundation for simulating decontamination efficacy and hazards
- Development of multi-generation approach to mature model to DT/OT and beyond (FY09)



DTRA Support, Chuck Fromer, Eric Lowenstein, Laura Sears



ECBC – Decon Sciences

Dr. Brent Mantooth, Dr. Teri Lalain, Zoe Hess, Dave Gehring

ECBC – Modeling Simulation & Analysis

Josh Combs, Mike Kierzewski



SAIC - Zach Zander, Morgan Hall, Matt Shue, Pam Humphreys



OMI – Dr. Roger Davis, Mike Dunkel

Questions?

Erin Shelly

Edgewood Chemical Biological Center


Phone: (410) 436-1937

Email: erin.shelly@us.army.mil

Backups

Decontaminants are evaluated by Performance or Hazards.

Decontaminant: material or process with the ability to reduce a hazard by neutralization or physical removal from the surface of interest.



Performance: How much agent is left.

Hazard: How much agent presented to unprotected personnel.

Hazards are a result of agent transported to or present at the surface after decontamination.


Contact Hazard: How much agent absorbed by touching surface.

Vapor Hazard: What vapor concentration generated by material.


Residual Agent: Mass of agent remaining in test material.

Three primary tests, defined in the 2007 Source Document, are used to answer :


Remaining Agent: how much agent in material.




Vapor Test: vapor emission rate, mass transport out of material (indirect agent distribution)



Contact Test: mass of agent transferred to contact sampler, (indirect agent distribution)



Process isolation tests are used to determine the impact and mass transport processes involved in each decontamination process step.



Methods defined in the 2007 Chemical Decontamination Source Document.

Testing is performed in a high-fidelity laboratory optimized for high-throughput decontamination testing.

Laboratory philosophy: *everything that can be controlled is, everything else is measured.*

Laboratory operates under supervision of a quality manager and is pursuing the implementation of an ISO-17025 quality system.

Analytical uses GC-MSD for HD with detection limits below current acquisition program requirements.

Confidence in laboratory data key for construction of semi-empirical model

- A minimum of 5 sample replicates are acquired for each set point
- Sample replicates are split across multiple days to capture day-to-day variations and prevent artificial trends

Modeling the panel test with various process conditions provides data that can be used for many applications and answer many questions.




Model can be thought of as an algebraic formula
Future work could 'rearrange' the equation to solve for any variable such as how long of a decon residence time to reach a requirement.

Keep this slide?? Move??

Currently model answers specific question:

Predict the post-decon hazards of emerging decontaminants to reduce the number of experiments required for evaluation.



Processes During Aging:

Sessile droplet evaporation


- Sessile droplet mass tracked to terminate sorption processes.

Sorption

- Dependent on material-agent interactions
 - Agent may be aBsorbed or aDsorbed
- Sorbed agent may evaporate
- Properties of material may require consideration of boundary conditions (e.g., thickness of paint)

Spreading


- Initially determines droplet contact area
- Material properties and interactions may invoke spreading changing contact area




Integrate existing models where available and ensure that assumptions are appropriate for this system.

Hu and Larson model assumes zero air flow.
Appropriate for test conditions.

Droplet Evaporation Models




Modeling Droplet Evaporation




Hu; Larson, *J. Phys. Chem. B.* **106**, 1334 (2002)

Surface Coverage



Age Time, Temperature, Material




All data points (on right graph) represent 1 x 1 µL drops (0.6 g/m²) HD


The contaminated surface area, age time, temperature and material contribute to the mass of agent absorbed and its distribution in the material.



The ability of a decontaminant to neutralize/remove agent is dependent on:

- Decon reaction kinetics – rate of neutralization (usually 1st order exponential).
- Ability to reach agent in material (penetration) determined by material-decon interactions.



Total agent mass vs. decon residence time shows convolution of decon penetration and reaction kinetics.






$$C(x,t) = C_0 \operatorname{erfc}\left(\frac{x}{2\sqrt{Dt}}\right)$$

Sidman *et. al.*,
ARCSL-CR-82034 (1982)

- Most techniques developed in the literature address 1D absorption of a uniform thin film.
- Discrete droplet absorption likely requires modeling 3D absorption.
- Currently investigating finite element and Monte Carlo approaches.



Each process step contributes towards efficacy and hazards.

Tests are executed to quantify contribution of each step to the system.

Rinse process alone may physically remove all agent.

Effect is dependent on agent-material interactions.

Material	Contamination	Decon	15M / 60M / RES
Glass	8 x 2 μL Drops (10 g/m^2)	Rinse only	Below Detection*
	2 x 0.5 μL Drops (0.63 g/m^2)		
Aluminum	8 x 2 μL Drops (10 g/m^2)	Rinse only	Below Detection*
	2 x 0.5 μL Drops (0.63 g/m^2)		


* Quant limit of 40 ng (0.02 mg/m^2)



8 x 2 μL Drops HD
on Aluminum







2 x 0.5 μL Drops HD
on Aluminum



2 x 0.5 μL Drops HD
on Glass

Multiple 'touches' are performed for contact test




- Touch defined as contact sampler in contact with surface for 15 minutes.
- First Touch (15M) starts 15 minutes after rinse – samples top surface of material.
- Second Touch (60M) starts 60 minutes after rinse – samples 'deeper' agent concentration.
- Need to model agent concentration profile to predict hazards.



Vapor concentration measured in small-scale vapor chamber enabling vapor emission rate calculation.

Vapor emission rate is a function of mass transport and agent concentration profile in material.

Emission rates can be used to approximate agent distribution in a material to estimate decon penetration.



Using the vapor emission rate of the lab-scale tests modeled in CREATIVE, vapor concentrations can be calculated for full-scale scenarios with simple scaling calculations.

Chamber Testing

Contaminate,
Decon,
Vapor
Measurement

Source Modeling CREATIVE

Emission Rate

Scenario

Inputs:
Timing
Enclosure Dimensions
Ventilation
Mixing
Source loading, location

Emission rates can be incorporated into other models such as VLSTRACK, SCIPUFF, JEM etc. to model complex systems

Scaling Calculations

Vapor
Concentration


Full-Scale Scenario Testing

Contaminate, Decon,
Vapor Measurement

Conditions:


Timing
Enclosure Dimensions
Ventilation
Mixing
Source loading, location

Temperature will affect all mass transport and chemical reaction kinetics.



Environmental Conditions (Continuous)

- Temperatures from 10-50 °C
- Relative humidity from 10-80%



HD / Silicone

64 min

$D: 16 \times 10^{-7} \text{ cm}^2/\text{s}$

$C_o: 90,000 \text{ } \mu\text{g}/\text{cm}^3$

$f1: 0.75$

$\delta x, \delta y: 0.0128 \text{ cm}$

$\delta z: 0.0064 \text{ cm}$


Calculated


$\delta t: 8.533 \text{ s}$

$r_x: 0.0833$

$r_y: 0.8333$

$r_z: 0.3333$






Example of a Drop
used for input:

Gray area indicates
the drop location on
coupon surface.

The drop is
positioned on the
coupon as specified
by the user.



Iodine used as a contrast agent to reveal sorption in silicone
Imaging experiments used to confirm model coefficients (diffusivity and saturation) and methods.

- Red – deposited agent drop.
- Orange = absorbed agent.
- Dark green – adsorbed agent.
- Blue = adsorbed agent and desorbed agent on surface.
- Purple = decontaminant.
- Green = reaction product.
- Light blue = rinse water.